
Purchase Date:____/____/____ Order/Customer Reference Number:_____

Replacement parts or products can be requested within the 1-year warranty period. Proof of purchase must be provided.
For additional warranty information, visit sunnydazedecor.com/pages/sunnydaze-decor-warranty
If you have any questions, comments or concerns, contact us at **833-982-1977**, or customerservice@sunnydazedecor.com

5-PANEL WALL ART

Review all assembly and care information before using this product. Save this manual for future reference.
Assemble components on a soft, clean surface to avoid damaging the finish.




***Style may vary. Drawing is for visual reference only.**

Inspect packaging to ensure all parts are accounted for before disposing of packing materials.

No.	Parts		Qty.
A		Wall Art	1
B		Wall Art	1
C		Wall Art	1
D		Wall Art	1
E		Wall Art	1

No.	Hardware		Qty.
1		34mm Screw	10
2		Wall Anchor	10

No.	Includes	Qty.
3	Wall Art Hanging Guide	1

Tools Required (not included)	
	Phillips Screwdriver
	Power Drill with 6mm Drill Bit
	Tape Measure
	Pencil

⚠ WARNING ⚠

CHOKING HAZARD — This item contains small parts that can be swallowed. Keep children and pets away during assembly.

⚠WARNING:


Manufacturer and seller expressly disclaim any and all liability from personal injury, property damage or loss, whether direct or indirect, or incidental, resulting from the incorrect attachment, improper use, inadequate maintenance, or neglect of this product.

ASSEMBLY

STEP 1

A: 1

CAUTION: Sharp edges.
Wear gloves during assembly.




Place Wall Art (A) face-down on a soft, clean surface.

Carefully measure the distance between the center of the flush mount brackets.

Use the included paper guide when hanging the five panels together. The hanging guide will have the panels spaced 1 inch apart and hung level on the wall.

STEP 2



Carefully measure and mark the wall with the mounting hole distance.

TIP: ***Double-check measurements to ensure accuracy.***

STEP 3



Drill pilot holes.

With the hanging guide drill right through the paper.

Discard the paper guide.

STEP 4

1: 2

2: 2



Press Drywall Anchors (1) into the pilot holes.

Install Screws (2) about 3/4 into the wall anchors.

STEP 5



Hang the wall art.

Repeat for the four other wall panels.

Care & Maintenance

SAFE USE: It is the installer's responsibility to ensure all mounting systems are properly installed. Failure to ensure adequate structural strength for the mounting system can result in personal injury or damage to the product. Only use the mounting system as described in the instructions.

CLEANING: Use a soft, dry cloth to dust. Gently wipe away minor marks with a slightly damp cloth, and dry with a soft cloth.

WARNING: THE ONE-YEAR WARRANTY DOES NOT COVER DAMAGES OR DEFECTS CAUSED BY THE APPLICATION OF CHEMICAL TREATMENTS, PROTECTIVE COATINGS, OR CLEANING PRODUCTS.

⚠ SAFETY STATEMENTS & WARNINGS ⚠

- For indoor, residential use only.
- This product is not intended for use by children.
- Avoid long-term exposure to sunlight.
- Avoid placing near heating or cooling vents as forced air can be very drying and could damage the set.
- Never use chemical cleaning products or abrasive materials to clean the product as they may damage the finish.
- Do not soak the product as doing so may result in permanent damage.

Any modification to the product or failure to follow recommended care will void the product warranty.

If you experience issues or the product was damaged during shipping,
please contact our customer service team through one of the methods mentioned at the top of page 1.
Please have the item number and order information ready to expedite response time.

⚠WARNING:

Manufacturer and seller expressly disclaim any and all liability from personal injury, property damage or loss, whether direct or indirect, or incidental, resulting from the incorrect attachment, improper use, inadequate maintenance, or neglect of this product.