


GLASS BIRD BATH

Review all assembly and care information before using this product. Save this manual for future reference.

Assemble components on a soft, clean surface to avoid damaging the finish.



Inspect packaging to ensure all parts are accounted for before disposing of packing materials.

NO.	PARTS	QTY.
A	Bowl*	1
B	Pedestal*	1

*Style may vary.
 Drawing is for visual reference only.

CHOOSING A LOCATION

Before assembly, carefully choose the location of the bird bath. Select a flat, level surface in partial shade. If placing the bird bath on a rough surface, such as on decorative rocks, we highly recommended using a large stepping stone or paver to prevent chipping and damaging the finish.

When moving the bird bath, remove the bowl from the pedestal; lifting the assembled bird bath while the bowl is attached to the pedestal may result in permanent damage that will not be covered by the product warranty.

ASSEMBLY

1. Gently place the pedestal in the desired location.
2. Align the notches on Bowl (A) with the grooves in Pedestal (B) and gently place the bowl onto the pedestal.
3. Gently but firmly twist the bowl to lock it onto the pedestal.

CLEANING

Cleaning 1-2 times per week is recommended.

1. Empty the old, stagnant water.
2. Wash the bowl using warm water and a soft cloth.
3. Rinse the glass bowl thoroughly with running water.
4. Fill the bowl with fresh, clean water.

If you experience issues with the product or it was damaged during transit, please contact our customer service team through one of the methods mentioned at the top of page 1. Please have the item number and order information ready to expedite response time.

! SAFETY STATEMENTS & WARNINGS !

- Do not install on uneven surfaces or loose soil.
- Disassemble the unit before moving; lifting by the bowl may damage the unit.
- Do not use a pressure washer, harsh chemicals, or abrasive materials to clean the unit.
- During extreme weather, empty the bird bath and store indoors; prolonged exposure to freezing temperatures, severe heat, and sudden temperature changes may cause the bird bath to crack or break.
- In high wind or storms, move bird bath indoors or secure to prevent tipping.

Any modification to the product or failure to follow recommended care will void the product warranty.

! WARNING:

Manufacturer and seller expressly disclaim any and all liability from personal injury, property damage or loss, whether direct or indirect, or incidental, resulting from the incorrect attachment, improper use, inadequate maintenance, or neglect of this product.