
Purchase Date:____/____/____ Order/Customer Reference Number:_____





Replacement parts or products can be requested within the 1-year warranty period. Proof of purchase must be provided.
For additional warranty information, visit sunnydazedecor.com/pages/sunnydaze-decor-warranty
If you have any questions, comments or concerns, contact us at **833-982-1977**, or customerservice@sunnydazedecor.com

WIRE CHRISTMAS TREE

Review all assembly and care information before using this product. Save this manual for future reference.
Assemble components on a soft, clean surface to avoid damaging the finish.



Inspect packaging to ensure all parts are accounted for before disposing of packing materials.


No.	Parts		Qty.
A		Stand Base	1
B		Lower Center Pole	1
C		Support Bar	2
D		Upper Center Pole	1
E		Upper Frame Rod	4
F		Lower Frame Rod	4
G		Tree Frame Ring	8
H		Tree Collar Panel	3
I		Collar Pin	3
J		Star Topper	1
K		Support Hub Plate	1
L		M6x10mm Screw	6

Included Tools	
	Hex Key

ASSEMBLY

STEP 1

A: 1
B: 1
C: 2




Place the Lower Center Pole (B) onto the Stand Base (A).

Cross the two Support Bars (C) and affix both to the lower center pole.

STEP 2

G: 6
L: 6




Connect the halves of a Tree Frame Ring (G) with two M6x10mm Screws (L). Repeat to create two more rings.

Starting with the largest, place the three tree frame rings onto the Support Bars (C) in descending order according to size.

STEP 3


D: 1
K: 1



Attach the Upper Center Pole (D) onto the Lower Center Pole (B). Place the Support Hub Plate (K) on top of the upper center pole.

STEP 4

E: 4
F: 4




Latch the hook of a Lower Frame Rod (F) through one of the four large loops of the largest tree frame ring. Next, latch the bottom hook of the Upper Frame Rod (E) through the ring of the lower frame rod. Latch the top hook of the upper frame rod through one of the four connecting holes in the Support Hub Plate (G)

Repeat the process for the three other rods.

ASSEMBLY

STEP 5


G: 2



Place the two largest Tree Frame Rings (G) onto the Lower Frame Rod (F) hooks from below.

STEP 6


G: 2



Place the other two small Tree Frame Rings (G) onto the Upper Frame Rod (E) hooks from above.

STEP 7

J: 1




Affix the Star Topper (J) to the center hole of the Support Hub Plate (G).

STEP 8

H: 3

I: 3



To assemble the tree collar, connect the three Tree Collar Panels (H) by placing a Collar Pin (I) in between each panel. Place the assembled tree collar under the tree.

Care & Maintenance

Indoor use only. Exposure to outdoor elements will result in erosion of the finish and structure of this unit; water and high moisture may cause the paint to chip or peel. The product warranty does not cover damages caused by exposure to outdoor elements.

Long-term exposure to sunlight may cause the paint finish to mellow in color, crack and peel.

Ensure weight is evenly distributed on the tree frame rings. Maximum weight capacity per ring (when evenly distributed):

1st Ring: 2 lbs (0.9 kg)

2nd Ring: 3.5 lbs (1.6 kg)

3rd Ring: 4.2 lbs (1.9 kg)

4th Ring: 5.5 lbs (2.5 kg)

5th Ring: 6 lbs (2.7 kg)

The total weight capacity for the Christmas tree is 21.2 lbs (9.6 kg).

LOCATION

Select a flat, level surface to place the decor; avoid high-traffic areas, especially where children and pets play.

CLEANING

Clean metal decor frequently to prevent dust, dirt and debris from building up.

1. Remove loose dust, dirt, cobwebs, and debris with a clean feather duster or a very soft-bristled brush, like a paintbrush.
2. Use a soft, dry cloth to gently wipe away dirt and debris from larger surfaces. For stuck-on dirt, dampen the cloth slightly and gently wipe soiled surfaces. **Never use cleaners, abrasive materials, or high-pressure sprayers to clean this item.**

⚠ SAFETY STATEMENTS & WARNINGS ⚠

- Recommended for indoor use only.
- Do not hang heavy objects from the hooks. Do not exceed the weight capacity as noted above.
- Ensure weight is evenly distributed to prevent the tree from tipping over.
- This is not a toy. Always supervise children and pets.

Any modification to the product or failure to follow recommended care will void the product warranty.

If you experience issues with assembly or the product was damaged during transit, please contact our customer service team through one of the methods mentioned at the top of page 1. Please have the item number and order information ready to expedite response time.

⚠WARNING:

Manufacturer and seller expressly disclaim any and all liability from personal injury, property damage or loss, whether direct or indirect, or incidental, resulting from the incorrect attachment, improper use, inadequate maintenance, or neglect of this product.