

DECORATIVE CHRISTMAS TREE BASE

Please read this manual carefully before use and save it for future reference.

Pitting on the surface of the statue is caused by air bubbles becoming trapped when the casting materials are poured into the mould. Over time, paint finishes will gradually mellow in color; this is part of the natural aging process.

LOCATION

Select a flat, level surface to place the tree base. Avoid high-traffic locations such as areas where children or pets play.

CLEANING

Clean your tree base often to prevent dirt and debris from building up.

1. Remove loose dirt, cobwebs, and debris with a very soft-bristled brush, like a paintbrush.
2. Gently rinse the tree base using water only and allow it to air-dry.



IMPORTANT INFORMATION



- For decorative purposes only. This item is not a toy.
- Store indoors during inclement weather and freezing temperatures.
- Do not use harsh chemicals, abrasive materials, pressure washers, or high-pressure sprayers to clean the tree base; doing so may damage the tree base or cause the paint to peel.

Any modification to the product or failure to follow recommended care will void the product warranty.



**For tree base assembly,
install bolts into base holes.**