



Purchase Date: ____/____/____ Order/Customer Reference #: _____

Thank you for choosing Sunnydaze Decor. We stand behind our brand and the quality of the items we sell. Replacement parts or products can be requested within the 1-year warranty period. Proof of purchase must be provided. This includes the date of the purchase as well as photos of the product defect. Photos are used to determine the cause of the defect and to provide future quality control. The request will be reviewed, and replacement pieces will be sent at our discretion. For warranty information, visit <https://tiny.cc/SunnydazeWarranty>

If you have any questions, comments or concerns, feel free to contact us by phone at 833-982-1977, by email: customerservice@sunnydazedecor.com, or via our contact us page at <https://tiny.cc/SunnydazeContact>

DECORATIVE PLANTER

Please read this manual carefully before use and save it for future reference.

USE & CARE

FILLING: Lightweight potting soil is recommended for filling the planter.

WATERING: Take care not to over-water plants.

EXPOSURE: Over time, sunlight and weather elements may degrade and change the color of this product.

MOVING: Always lift the planter from the bottom when moving it, lifting by the decorative elements of the planter may cause it to break. Slowly and gently set the planter down to prevent breakage.

CLEANING: Gently brush loose debris using a soft-bristle brush, like a paintbrush. Rinse under a faucet using lukewarm water and allow to air dry.

WINTER CARE & STORAGE: Store in a dry, indoor location. To prevent cracking, empty and store indoors during freezing temperatures.

Any modification to the product or failure to follow recommended care will void the product warranty.

⚠ WARNING: Manufacturer and seller expressly disclaim any and all liability from personal injury, property damage or loss, whether direct or indirect, or incidental, resulting from the incorrect attachment, improper use, inadequate maintenance, or neglect of this product.